



INSTRUCTIVO PARA PROGRAMAR SCANNER MS9520

Enter/Exit Configuration Mode



Recall Defaults



* Enable UPC/EAN



* Enable UPC-A





* Enable UPC-E



Do Not Transmit
EAN-13 Check Digit



Disable LF Suffix



Do not Transmit
UPC-A Check Digit





Expand UPC-E to 12 Digits



Convert UPC-A to EAN-13



Disable Two Digit
Redundancy



Enter/Exit Configuration Mode



Cualquier duda, comunicarse a Sistemas Sierra.